

Features

- Continuous level measurement for bulk solids and liquids
- Measurement not affected by temperature changes, powder or vapours
- Measure range for rope version: up to 30m
- Measure range for rod version: up to 3m
- Measure range for coax probe: up to 3m
- Process temperature: from a - 40 to +150°C
- Process pressure: from -1 to 40bar
- Easy on-site configuration via VL602 module display
- Easy on-site calibration without product handling. Empty and full distance setting via matrix display
- Two-wire and four-wire technology
- Analogic output 4÷20mA
- HART protocol
- Level measurement and echo signal curve visualisation on matrix display
- Storage and recognition system for false echo signals



Principle

The high frequency pulses, emitted by the transmitter, travel along the detecting component (steel rope, probe or rod). They are reflected by the product surface, recorded by the electronic unit and converted in level data.

Characteristics

RWL transmitters are suitable for heavy process conditions because they are equipped with a modern processor and with the **EchoDiscovery** management software.





EchoDiscovery software permits the recognition and the filtering of false echo signals in order to obtain a correct level measurement.

RWL versatility allows the utilisation in heavy process conditions as high temperature, high pressure or low dielectric constant.

The low energy of the radar pulse avoids problems to process connection, to the environment and to operators.

1. Technical data

1.1 Selection option

Version	RWL51	RWL52PA_	RWL53PA	RWL54
Probe type	Ø4/6mm (rope) Ø10mm (rode)	Ø10mm (rod)	Ø28mm (coax)	Ø4/6mm (rope) Ø10mm (rode)
				
Applications	Level measurement for liquids/solids	Level measurement for liquids/solids	Level measurement for liquids with low dielectric constant	Level measurement for liquids/solids
Range	Rope:10m Ø4mm ; 30m Ø6mm / Rod: 3m	3m	3m	Rope:10m Ø4mm ; 30m Ø6mm / Rod: 3m
Accuracy	±010mm (see diagram)	±010mm (see diagram)	±010mm (see diagram)	±010mm (see diagram)
Process connection (AISI 316L)	1 1/2" G 1 1/2 " NPT 2" G	DN50 PN16 DN80 PN16 DN100 PN16 DN150 PN16	1 1/2" G 2" G	1 1/2" G 1 1/2 " NPT 2" G
Material	AISI 316L / PTFE	AISI 316L / PTFE	AISI 316L / PTFE	AISI 316L / PTFE
Process temperature	-40 +150°C	-40 +150°C	-40 +150°C	-40 +200°C
Process pressure	-1.... 40bar	-1.... 40bar	-1.... 40bar	-1.... 40bar
Max pulling force	(see diagram)	Unimportant	Unimportant	(see diagram)
Housing	Aluminum	Aluminum	Aluminum	Aluminum
Cover	Aluminum + Glass	Aluminum + Glass	Aluminum + Glass	Aluminum + Glass
Sealing material	Viton (-30 ÷ +150°C) Kalrez (-40 ÷ +150°C)	Viton (-30 ÷ +150°C) Kalrez (-40 ÷ +150°C)	Viton (-30 ÷ +150°C) Kalrez (-40 ÷ +150°C)	Viton (-30 ÷ +150°C) Kalrez (-40 ÷ +150°C)
Protection degree	IP67	IP67	IP67	IP67

1.2 Power supply

Two-wire version:

- input voltage: 15÷36Vdc
- consumption: max. 22.5mA 0.8W
- max ripple: <100Hz, U_{ss}>1V; 100Hz÷100KHz, U_{ss}<10mV

Four-wire version

- input voltage: 20 ÷ 72Vdc; 230Vac

2 chamber four-wire version

- input voltage: 24Vdc ±10%; 230Vac ±10%
- consumption: <1W


1.3 Output

- output signal: 4÷20mA / HART
- resolution: 1,6microA
- fault fixed signal: 20.5mA; 22mA; 3.8mA

Load:

- two-wire version: see diagram
- four-wire version: max. 500ohm
- Integration time: 0÷99s, programmable

2 Wires load resistance diagram




1.4 Cable connection

- cable input: 2 x M20x1.5
- connecting terminals: max. cable section 2.5mm²


1.4 Accuracy

RWL51 / RWL54




Rope

RWL51 / RWL52



Rod

RWL53







Coax

1.5 Pulling


In solid measurement the pulling force is determined by the silo diameter and by product level.
See in the below diagrams some examples related to models **RWL51**

Metal vessel with smooth sidewall


- Diameter: 12m
- - - Diameter: 9m
- Diameter: 6m
- _____ Diameter: 3m




Grain




Sand



Plastic particles



Cement



2. Basic requirements

The **RWL** system measures the distance between the reference plane (lower edge of the flange) and the product surface.

The minimum distance between the reference plane and the maximum level is indicated as Top blanking zone (1) and the area around the end of the probe is indicated as Bottom blanking zone (4).

Inside both blanking zones is impossible to obtain a correct measurement.




Fig.1

- (1) Top blanking zone
 - (2) Empty =0
 - (3) Measurement range
 - (4) Bottom blanking zone
 - (5) Reference plane
 - (6) Length of the probe
- NB. Inside both blanking zones (1 ,2) is impossible to obtain a correct measurement.

WARNING - To avoid electronic equipment damage, mechanical removal the RWL transmitters before doing any arc welding in their vicinity.

The best mounting position in a conical vessel with flat top, is the middle of the vessel's top, as shown in fig 2.




Fig.2




Fig.3

If possible, avoid installation with sockets; otherwise try to reduce the dimensions.

In case of long socket mounted on small vessels or in case of product with low dielectric constant, is recommended the use of RWL56 version.




Fig.4

- 1) Wrong : The probe must not be positioned above the filling stream.
- 2) Correct: For outdoor mounting use a protection cover (for sun and rain)




Fig.5

In order to avoid problems caused by humidity, the connecting cable must be positioned as indicated in fig 5.

3. Electrical connections

3.1 Standard conditions

The electric supply voltage can be different according to the transmitter model. Always check the correct value indicated on the transmitter label.

It is necessary to observe installation codes and safety operations for the site and the plant conditions.

3.2 Power supply

3.2.1 4÷20mA / HART, 2-wire

The same cable is used for both electrical supply and for 4÷20mA signal (fig.6). The correct values of the electrical supply are indicated on the product technical data sheet.

3.2.2 4÷20mA / HART, 4-wire

2 different cables are used for electrical supply and for 4÷20mA signal (fig.7).

3.3 Connecting cables

Use a 6÷11mm diameter cable to ensure the tightness on cable glands. Use shielded cables in order to avoid transient current on the shield.

3.3.1 4÷20mA / HART


For 2-wire model use a single cable (fig.6). For 4-wire model use two cables (fig.7).

3.4 Earthing of cable shield

The cable shield must be earthed at both ends. Insert a ceramic capacitor, 1nF 1500V type, in order to avoid transient currents on the shield.

3.5 Wiring diagrams

See the different versions in Fig.6/7



4. CONFIGURATION

4.1 Setting modalities

The **RWL** radar level transmitter has 3 configuration and setting modalities:

- by programming display
- by **SGMware** communication software
- by HART handheld

4.2 SGMware

4.2.1 Connection by HART line (fig.10)

- 1) RS232 cable connector
- 2) RPL5X with HART communication protocol
- 3) HART adapter used with COMWAY converter
- 4) Resistance 250ohm
- 5) COMWAY converter




Fig.10

4.2.2 Connection by HART programmer (fig.11)

- 1) HART programmer
- 2) RPL5X with HART handheld
- 3) Resistance 250ohm




Fig.11

5. PROGRAMMING

5.1 Programming display

The **VL602** programming display (fig.13) has a large matrix LCD (fig.13), and can be easily connected to the unit (with a clockwise rotation) by sliding contacts. It can be mounted and removed while the instrument is working.. The multilingual programming guide allows an easy and fast start up through the keyboard (fig.23). The display also shows the distance and the instantaneous level during the operating conditions, through its transparent cover.




Fig.23

- OK** - Programming access
- Option confirmation
- Parameters value confirmation
- ↶** - Value selection
- Scroll parameters
- ↑** - Parameters value modification
- BK** - Exit programming
- Back to previous menu
- "RUN" and "ECHO WAVE" access

5.2 Description

The Menu Structure is shown in the next paragraphs.

When the arrow ► is positioned on the right side of the writing, press **OK** to choose the parameter setting menu, or press **↶** to select the next parameter. When the arrow ► is positioned on the left side of the writing, press **↶** to select the next menu and press **OK** to confirm. To go back to previous menu press **BK**.

5.3 Programming menu

5.3.1 Basic settings

In this menu is possible to set the basic adjustments of the sensor.

5.3.2 Display

In this menu you can setup the sensor display and adjust the B/W contrast for LCD.

5.3.3 Diagnostic

In this menu you can check and test the sensor. You can view the measurement peak values, the measurement status and the Echo-curve.

5.3.4 Service

In this menu you can set the false Echo-curve, current output, language and HART mode.

5.3.5 Info

In this menu you can see the sensor information, including type, serial number, date of manufacture and software version.

5.4 Program mode

From "RUN" mode press **OK** to enter "PROGRAM" mode. Press **BK** to quit.

5.5 Parameter setting and changing

On entering Parameter Editing, the first digit of the edited parameter will be displayed in black background .


Press **↑** to modify the digit and press **↶** to edit the next digit.


At the end of the operations, press **OK** to confirm and to store the modifications

To select a parameter during the setting, press **↶** and confirm your choice with **OK** .

6. MENU STRUCTURE


The following diagrams show the structure of the configuration menus:





7. BASIC SETTINGS (1)


From "RUN" mode press **OK** to enter the configuration menu. Press **↶** to select and **OK** to confirm. The menu item number is always displayed on the top right corner. By selecting and confirming "**Basic settings**" in menu **1**, the display will show in sequence:



- ↶** Select menu
 - OK** Confirm
- Note-The menu item number is displayed on the top right corner.

7.1 Min. adjustment (1.1)


Press **OK** to modify the percentage value (see par. 2.4). Press **OK** again to confirm and to edit the corresponding distance value. After the setup press **OK** to confirm. Press **↶** to enter menu **1.2**.
Note - The lower value (**d**) shows the measured instantaneous distance.



- OK** Enter editing menu
- ↶** Select the value
- ↑** Modify the value
- OK** Confirm
- ↶** Go to menu 1.2

7.2 Max adjustment (1.2)


Press **OK** to modify the percentage value (see par. 2.4). Press **OK** again to confirm and to edit the corresponding distance value. After the setup press **OK** to confirm. Press **↶** to enter menu **1.3**.
Note - The lower value (**d**) shows the measured instantaneous distance.




- OK** Enter editing menu
- ↶** Select the value
- ↑** Modify the value
- OK** Confirm
- ↶** Go to menu 1.3

7.3 Medium (1.3)

Each medium has different reflective properties. In this menu is possible to choose between liquid or solid medium.
Press **OK** to enter medium selection menu. Press **↶** to select the medium and **OK** to confirm and to enter submenu **1.3.1**




- OK** Enter editing menu
- ↶** Go to menu 1.4
- ↶** Select parameter
- OK** Confirm and enter submenu 1.3.1



- OK** Select the medium type
- ↶** Confirm the selection


7.3.1 Fast level change (1.3.1)

Setting it to "No", with a variation of size > 1 m, the system late 30s the new measure acquisition, after which updates the output signal according to the parameter "Damping" (1.4), with variations <1m output signal upgrade is a "Reading Retardation" parameter function (1.4). Default setting is "Yes". Press **OK** to enter parameter modification, press **↶** to enter the next menu **1.5**



- OK** Enter editing menu
- ↶** Go to submenu 1.5

With **↶** you can select the parameter setting, with **OK** you can confirm your selection and go back to previous submenu.




- ↶** Select parameter
- OK** Confirm and go back to previous submenu

7.3.2 First echo (1.3.2)

This parameter sets the first valid echo signal acceptance .


Press **OK** to enter parameter modification, press **↩** to enter the next submenu **1.3.3** (par.3.3.c).



- OK** Enter editing menu
- ↩** Go to next submenu 1.3.3

With **↩** you select the parameter setting, with **OK** you confirm your selection and go back to previous submenu:

- Normal; automatic
- Small; decrease first echo by 10dB
- Big; increase first echo by 10dB
- Bigger; decrease first echo by 40dB
- Biggest; increase first echo by 40dB




- ↩** Select parameter
- OK** Confirm and go back to previous submenu

7.3.3 Agitated surface (1.3.3)

Large angle repose (1.3.3)

This submenu is related to the previous selection in menu **1.3**: by selecting “**Liquid**” in menu **1.3**, the display will now show “**Agitated surface**”; In both cases the default setting is “**No**”.


Press **OK** to enter parameter modification, press **↩** to enter the next submenu.




- OK** Enter editing menu
- ↩** Go to next submenu 1.3.4
Note - This window is displayed only in case of selected option “**Liquid**” in menu 1.3

by selecting “**Solid**” in menu **1.3**, the display will now show “**Large angle repose**”.


Press **OK** to enter parameter modification, press **↩** to enter the next submenu.



- OK** Enter editing menu
- ↩** Go to next submenu 1.3.4
Note - This window is displayed only in case of selected option “**Liquid**” in menu 1.3



- OK** Enter editing menu
- ↩** Go to next submenu 1.3.4
Note - This window is displayed only in case of selected option “**Solid**” in menu 1.3




- ↩** Select parameter
- OK** Confirm and go to next submenu

7.3.4 Foaming (1.3.4)


Powder dust (1.3.4)

This submenu is related to the previous selection in menu **1.3**: by selecting “**Liquid**” in menu **1.3**, the display will now show “**Foaming**”; In both cases the default setting is “**No**”.

Press **OK** to enter editing menu and press **↩** to select the option. Then press **OK** again to confirm




- OK** Enter editing menu
- ↩** Go to next submenu 1.3.5
Note - This window is n case of selected option “**Liquid**” in menu 1.3




- ↩** Select parameter
- OK** Confirm and go to next submenu

by selecting **"Solid"** in menu 1.3, the display will now show **"Powder dust"**.



- Enter editing menu
- Go to next submenu **1.3.5**
- Note -This window is displayed in case of selected option **"Solid"**in menu 1.3

Press to enter editing menu and press to select the option. Then press again to confirm and to go



- Enter editing menu
- Go to next submenu


7.3.5 Low DK (1.3.5)

The Dielectric Constant is very important in order to obtain a correct measurement. In case of products with low dielectric constant (asbestos or non-conductive liquids), set the parameter on **"Yes"**.

The default setting is **"No"**.


Press to enter parameter modification and press to select the parameter.

Press again to confirm and to go back to previous submenu.



- Enter editing menu
- Go to next submenu

Note-This window is displayed only in case of selected option **"Liquid"**in menu 1.3




- Select parameter
- Confirm

Selecting **"Yes"** must enter the height of empty vessel.

Press again and enter the Empty Span.

Press to confirm and to go back to previous submenu.




- Enter editing menu
- Select the value
- Modify the value
- Confirm
- Go to the next menu

7.3.6 Measure in tube (1.3.6)


This window is displayed only by selecting **"Liquid"** in menu 1.3.

If the transmitter is installed into a calm or bypass pipe it is necessary to set **"Yes"**. The default setting is **"No"**.

Press to enter parameter modification and press to make the selection. Confirm with and go next submenu **"Measure diameter"**.




- Enter editing menu
- Go to next submenu **1.3.1**
- Note - This window is displayed only in case of selected option **"Liquid"**in menu 1.3



- Select parameter
- Confirm and go to next submenu


Press again and enter the diameter value, as specified in par. 2.4. Press to confirm and to go back to previous submenu.



- Enter editing menu
- Select the value
- Modify the value
- Confirm

7.3.7 Micro DK (1.3.1)

Normally when electronic constant is smaller than 1.4, the direct echo from the medium is low and hard to detect. However by measuring the echo reflected from the base of the vessel, the height of the medium can be measured. Two parameters are needed to be entered here. 1. Height of empty vessel. 2. True medium height or medium electronic constant, these two parameters are related, entering either one is accepted. The precision of parameters will affect the precision of the measurement.



1.3

liquid
solid
▶ Micro DK

1.3.1


Micro DK
Empty Span 10.00m
True level 0.00m
DK 1.00

Enter editing menu (OK)
Go to next submenu (↻)

Enter editing menu (OK)
Select the value (↻)
Modify the value (↑)
Confirm (OK)

7.4 Damping (1.4)

Press **OK** to enter parameter modification and set the value (in seconds) and confirm with **OK**.
Press **↻** to go to next menu **1.5**.




1.4

Damping
0S

Enter editing menu (OK)
Select value (↻)
Modify the value (↑)
Confirm (OK)
Go to next menu 1.5 (↻)

7.5 Signal threshold (1.5)

Press **OK** to enter parameter modification and set the value (in seconds) and confirm with **OK**.
Press **↻** to go to next menu **1.6**.




1.6

Signal threshold
20mV

Enter editing menu (OK)
Select value (↻)
Modify the value (↑)
Confirm (OK)
Go to next menu 1.5 (↻)

7.6 Mapping curve (1.6)

The relationship between the measured value and the output signal 4÷20mA can be linear or non linear. In this menu you can set the output signal 4÷20mA: “**linear**” or “**non-linear**”. The setting of “**non-linear**” mode must be done with **SGMware** software through PC.
Press **OK** to select the 4÷20mA output mode, press **↻** to enter the next menu.



1.6


Mapping curve
Linear ▶

Enter editing menu (OK)
Go to next menu 1.7 (↻)

Note -The setting of a “non-linear” mapping curve must be done with **SGMsoftware** through

7.7 Scaled units (1.7)

Press **OK** to enter parameter modification.
Press **↻** to go to next menu **1.8**.



1.7


Scaled units
height ▶
m ▶

Enter editing menu (OK)
Go to next menu 1.8 (↻)

The selectable options are:

- **Height**; m, ft, in, cm, mm
- **Massa**; Kg, t, lb
- **Flow**; m³/s, m³/h, ft³/s, ft³/m, gal/s, gal/min, gal/h, l/s, l/min, l/h
- **Volume**; m³, l, hl, ft³, in³

Press **↻** to make the selection and press **OK** to confirm




1.7

Scaled units
▶ Height Volume
Weight No unit
Flow

Select the parameter (↻)
Confirm and enter to relevant submenu (OK)

7.8 Scaling (1.8)

Press **OK** to modify the 0% value, press **↻** to enter the next menu. Set the value and confirm with **OK**.
Press **OK** again to modify the 100% value. Set the value and confirm. Press **↻** to enter the next menu.




1.8

Scaling
0%= 0.00 m
100%= 0.00 m

Enter editing menu (OK)
Select the value (↻)
Modify the value (↑)
Confirm (OK)
Go to next menu 1.9 (↻)

7.9 Range (1.9)


Press **OK** to modify the value expressed in meters, press **↻** to enter the next menu **1.10**.
Set the value and confirm with **OK**.
Press **↻** to enter the next menu **1.10**.



- OK** Enter editing menu
- ↻** Select the value
- ↑** Modify the value
- OK** Confirm
- ↻** Go to next menu **1.10**

7.10 Near blanking (1.10)


Press **OK** to modify the value expressed in meters, press **↻** to enter the next menu **1.11**.
Set the value and confirm with **OK**.
Press **↻** to enter the next menu **1.11**.



- OK** Enter editing menu
- ↻** Select the value
- ↑** Modify the value
- OK** Confirm
- ↻** Go to next menu **1.11**

7.11 Sensor tag (1.11)

Press **OK** to modify the parameter, press **↻** to enter the starting menu **1.1**.
Set the value, as specified in par 2.4, and confirm with **OK**.
Press **↻** to enter the starting menu **1.1**.




- OK** Enter editing menu
- ↻** Select the value
- ↑** Modify the value
- OK** Confirm
- ↻** Go back to starting menu **1.1**

8. DISPLAY (2)

From "RUN" mode press **OK** to enter the configuration menu: the following menu will be displayed (1). Press **OK** to select the item and press **↻** to confirm. The menu item number is always displayed on the top right corner.

By selecting and confirming "Display" in menu 2, the display will show in sequence:




- ↻** Select menu
- OK** Confirm

Note-The menu item number is displayed on the top right corner.


8.1 Display value (2.1)

Press to **OK** to enter parameter modification and press **↻** to enter next menu **2.2**.



- OK** Enter editing menu
- ↻** Go to next menu **2.2**

Select with **↻** the measured value you want to be displayed and press **OK** to confirm and to go back to previous menu.




- ↻** Select the parameter
- OK** Confirm and go back to menu **2.1**


8.2 LCD contrast (2.2)

Press **OK** to enter parameter modification and press **↩** to enter next menu 2.1.

Press **↑** to increase the contrast and press **↩** to decrease. Press **OK** to confirm and to go back to previous menu.



- OK** Enter editing menu
- ↩** Go to menu 2.1



- ↩** Decrease the contrast
- ↑** Increase the contrast
- OK** Confirm and go back to menu 2.2


9. Diagnostic (3)

From "RUN" mode press **OK** to enter the configuration menu: the following menu will be displayed (1).

Press **↩** to select the item and press **OK** to confirm.

The menu item number is always displayed on the top right corner.

By selecting and confirming "Diagnostic" in menu 3, the display will show in sequence:




- ↩** Select programming menu
 - OK** Confirm selection
- Note-The menu item number is displayed on the top right corner.

9.1 Peak values (3.1)

In this menu are recorded the min. and max. distance values. They can be cleared to zero in menu 4.3.


Press **↩** to enter the next menu 3.2.



- ↩** Go to next menu 3.2

9.2 Measurement status (3.2)


The display shows the level of the receiving signal and the general status of the sensor. Press **↩** to enter menu 3.3.



- ↩** Go to next menu 3.3


9.3 Choose curve (3.3)

Press **OK** to enter curve selection and press **↩** to enter menu 3.4.



- OK** Enter editing menu
- ↩** Go to next menu 3.4

Press **↩** to select the curve and press **OK** to confirm and to enter menu 3.4.



- ↩** Select curve
- OK** Confirm and go to next menu 3.4


9.4 Echo curve (3.4)

Press **OK** to enter zoom submenu of the selected curve. Press **↩** to enter the next menu **3.5**.

The 2 echo curve indicators show:


- ↓ - actual measure
- ⇓ - estimated measure

In normal operating conditions the indicators coincide in position and measure.



- OK** Enter Zoom sub-menu
- ↩** Go to next menu **3.5**


Press **↩** to select the zoom mode and press **OK** to confirm. The display will then show the curve.




- ↩** Sel. zoom mode
- OK** Confirm and see the curve

In case of **"X-zoom"** selection, you must proceed in the following way:

- press **→** to move right the first line (opening line) of the zoom window
- press **OK** to confirm the position and to edit the second opening line
- press **→** to move right the second line (closing line) of the zoom window
- press **OK** to confirm the position and to visualize the zoom window of the curve



- ↑** Move the first zoom line
- OK** Confirm first line position
- ↑** Move the second zoom line
- OK** Confirm second line position and see the zoom window




- OK** Go to submenu Zoom
- BK** Go back to menu **3.4**
- ↩** Go to next menu **3.5**

9.5 Simulation (3.5)


The **"Simulation"** menu is used to simulate the 4-20mA current output. There are three options:

- **Percent:** the output current is defined as a percent value (0% correspond to 4mA and 100% to 20mA)
- **Current:** the output current is defined as a current value
- **Distance:** the output current is defined by a distance value, in relation to Min adjustment (**1.1**), Max adjustment (**1.2**) and Mapping (**1.6**).

Press **OK** to select simulation mode, press **↩** to go back to menu **3.1**.



- OK** Enter the editing menu
- ↩** Go back to menu **3.1**




- ↩** Select simulation mode
- OK** Confirm

10. Service (4)

From "RUN" mode press **OK** to enter the configuration menu. The following menu will be displayed (1).

Press **↻** to select the item and press **OK** to confirm the selection. The menu item number is always displayed on the top right corner. By selecting and confirming "Service" in menu 4, the display will show in sequence:




- ↻** **OK** Select programming menu
- ↻** **OK** Confirm selection
- Note - The menu item number is displayed on the top right corner.


10.1 False echo (4.1)

This function gets rid of interfering signals caused by obstacles placed between the sensor and the product surface (i.e. brackets, agitators or pipes). Press **OK** to enter the False echo storing/modifying mode, press **↻** to enter the next menu 4.2. Press **↻** to select the function, then press **OK** to confirm and to enter the next sub-menu in case of "Update/Create new". The 0% level condition is required to record the echo curve False.

Press **OK** to set the parameter and to confirm. After the confirmation the system goes back to menu 4.2.




- ↻** **OK** Enter editing menu
- ↻** **↻** Go to next menu 4.2



- ↻** **↻** Select function
- ↻** **OK** Confirm selection and go to next sub-menu in case of **update/create new**


10.2 Current output (4.2)

Press **OK** to enter current output sub-menu, press **↻** to enter the next menu 4.3




- ↻** **OK** Enter editing menu
- ↻** **↻** Go to next menu 4.3

Press **↻** to select the current output function, press **OK** to confirm and enter the selected item, in sequence:




- ↻** **↻** Select mode
- ↻** **OK** Confirm and go to submenu

- **Output mode**; direct (4÷20mA) or indirect (20÷4mA) output. Press **↻** to select the current output and then press **OK** to confirm and to go back to sub-menu 4.2




- ↻** **↻** Select parameter
- ↻** **OK** Confirm and go back to menu 4.2

- **Failure mode**; output signal forcing in case of system failure (no change/, 20.5mA or 22.0mA)
Press  to select the parameter and press  to confirm and to go back to sub-menu **4.2**



  Select parameter
  Confirm and go back to menu **4.2**


- **Min. current**; min. value of the signal (3.8mA or 4mA).
Press  to select the value and press  to confirm and to go back to sub-menu **4.2**



  Select parameter
  Confirm and go back to menu **4.2**


10.3 Reset (4.3)

Press  to enter reset sub-menu, press  to enter the next menu **4.4**



 Enter editing menu
  Go to next menu **4.4**


Press  to select the resetting parameters and press  to confirm. The system is now reconfigured with default values.



  Select parameter
  Confirm and reset

10.4 Units of measurement (4.4)


Press  to enter the units of measurement menu: metric system (m) or British system (ft). Press  to enter the next menu **4.5**.



 Enter editing menu
  Go to next menu **4.5**

10.5 Language (4.5)


Press  to enter the language selection menu: Italian or English. Press  to enter the next menu **4.6**.



 Enter editing menu
  Go to next menu **4.6**


10.6 HART operation mode (4.6)

Press  to enter the **HART** operation mode: standard or multidrop. Press  to enter the next menu **4.7**.



 Enter editing menu
  Go to next menu **4.7**

Press  to select **HART** communication mode: **“Standard”** (address 0) or **“Multidrop”** (you must input the address. On the same line there cannot be 2 or more units with the same address). Press  to confirm: the system is now reconfigured with default values.




HART operation mode 4.6
Standard ►
Multidrop

  Select parameter
  Confirm and reset

10.7 Copy sensor data (4.7)


Press  to enter the copy sensor data menu: copy from sensor or copy to sensor. Press  to enter the next menu **4.8**



Copy sensor data 4.7
Copy sensor data ?

  Enter editing menu
  Go to next menu **4.8**

Press  to select the operation: with **“Copy from sensor”**, it is possible to save the sensor settings; with **“Copy to sensor”**, all the previously saved sensor settings are restored. Press  to confirm: the system is now reconfigured with default values.




Copy sensor data 4.7
Copy from sensor ►
Copy to sensor

  Select option
  Confirm


10.8 PIN (4.8)

Press  to enter PIN sub-menu: if the PIN is unactive the option will be **“Enable?”**. Press  to enter a 4 digit PIN code. If the PIN is active the option will be **“Cancel?”**. Press  to go back to menu **4.1**



PIN 4.7
Enable?

  Enter editing menu
  Go back to menu **4.1**




PIN 4.7
Cancel ?

  Enter editing menu
  Go back to menu **4.1**

11. Info (5)


From "RUN" mode press **OK** to enter the configuration menu. The following menu will be displayed (1). Press **↶** to select the item and **OK** to confirm. The menu item number is always displayed on the top right corner.

By selecting and confirming "Info" in menu **5**, the display will show in sequence:




↶ Select programming menu
OK Confirm selection
Note - The menu item number is always displayed on the top right corner.

11.1 Sensor type / Serial number (5.1)
Press **↶** to go to next menu **5.2**.



↶ Go to next menu **5.2**


11.2 Date of manuf./ Software version (5.2)
Press **↶** to go back to menu **5.1**





↶ Go back to menu **5.1**

12. Mechanical dimensions

12.1 Dimensions





RWL - Warranty

Products supplied by SGM LEKTRA are guaranteed for a period of 12 (twelve) months from delivery date according to the conditions specified in our sale conditions document. SGM LEKTRA can choose to repair or replace the Product. If the Product is repaired it will maintain the original term of guarantee, whereas if the Product is replaced it will have 12 (twelve) months of guarantee. The warranty will be null if the Client modifies, repair or uses the Products for other purposes than the normal conditions foreseen by instructions or Contract. In no circumstances shall SGM LEKTRA be liable for direct, indirect or consequential or other loss or damage whether caused by negligence on the part of the company or its employees or otherwise howsoever arising out of defective goods.

RWL - Factory test certificate

In conformity to the company and to the check procedure I certify that the equipment:

RWL part nb.

is conform to the technical requirements on Technical Data and is made in compliance with the SGM-LEKTRA procedure

Quality Control Manager

Production and check date

SGM-LEKTRA S.r.l. Via Papa Giovanni XXIII, 49 - 20090 Rodano (MI) - ITALY-
tel: ++39 0295328257 fax: ++39 0295328321
web: www.sgm-lektra.com e-mail: info@sgm-lektra.com